

PS-351x G2/PS-361x G2 JUMPER SETTING

Ver. A1

- **JP1 : COM3 Pin1 connected Setting**

Pin 1-2 Short : COM3 Pin1 connected to 12V

Pin 2-3 Short : COM3 Pin1 connected to DCD

- **JP2 : COM1/COM2 Pin1 connected Setting**

Pin 1-3 Short : COM1 Pin1 connected to 12V

Pin 3-5 Short : COM1 Pin1 connected to DCD

Pin 2-4 Short : COM2 Pin1 connected to 12V

Pin 4-6 Short : COM2 Pin1 connected to DCD

- **JP3 : COM4 Pin1 connected Setting**

Pin 1-2 Short : COM4 Pin1 connected to 12V

Pin 2-3 Short : COM4 Pin1 connected to DCD

- **JP4 : For CR open/close status port selection**

Pin 1-3 、 2-4 Short: For COM1

Pin 3-5 、 4-6 Short : For COM5

- **SW1 : Clear CMOS Setting**

DIP	Switch select	
1 & 2	1: ON, 2: ON	Reserved
	1: ON, 2: OFF	Normal Operation
	1: OFF, 2: ON	Clear CMOS
	1: OFF, 2: OFF	Reserved
3	OFF	Reserved

- **COM1~COM4 +5V through BIOS ; VGA +12V through BIOS**

Press Esc to access Advanced\OEM IO Configuration\

VGA DSUB 12V : Disabled

COM1 DB9 5V : Disabled

COM2 DB9 5V : Disabled

COM3 DB9 5V : Disabled

COM4 DB9 5V : Disabled

